



MATRIX KEYBOARDS

ELITE SERIES

USER MANUAL



BASIC KEYBOARD FUNCTIONS

◆C - COPY	◆P - PRINT	◆[- DECREASE FONT SIZE
◆X - CUT	◆A - SELECT ALL	◆] - INCREASE FONT SIZE
◆V - PASTE	◆F- FIND	◆SCROLL WHEEL - INC. OR DEC, FONT
◆Z - UNDO	◆O - OPEN	HOLD CTRL + CORRESPONDING KEY
◆Y - REDO	◆S - SAVE	
◆R - REFRESH	◆N - NEW	
◆ALT + FN + M - CTRL + ALT + DELETE		
◆BACKSPACE - DELETES PREV. WORD		






FUNCTIONS AND FUNCTION LOCK

PRESS FN + CORRESPONDING KEY
FN + E FOR COMMAND ONLY LOCK
REPEAT TO TURN OFF OR FN + Q

◆1 - F1	◆2 - F2
◆3 - F3	◆4 - F4
◆5 - F5	◆6 - F6
◆7 - F7	◆8 - F8
◆9 - F9	◆0 - F10
◆-(MINUS) - F11	◆= - F12
◆/ - ?	◆ALT - /
◆MENU - RIGHT CLICK	






COMMANDS AND COMMAND LOCK

PRESS FN + R CORRESPONDING KEY
FN + R FOR COMMAND ONLY LOCK
REPEAT TO TURN OFF OR FN + Q

◆ U - PRINT SCREEN	◆ K - HOME
◆ I - SCROLL LOCK	◆ L - PAGE UP
◆ J - INSERT	◆ M - DELETE
◆ . - PAGE DOWN	◆ , - END
◆ O - PAUSE/BREAK	





RGB FUNCTIONS

PRESS FN +] FOR LIGHT CYCLE

* INDICATES CYCLE LIGHT FUNCTION

PRESS FN + BACKSPACE TO TURN OFF

◆SINGLE KEY*
◆PRESSED KEY ROW*
◆SOUND VISUALIZER*
◆RIPPLE FROM PRESSED KEY*
◆FN + [- BRIGHTNESS UP
◆FN + P - BRIGHTNESS DOWN
◆FN + ; - LIGHT SPEED SLOWS
◆FN + ' - LIGHT SPEED FASTER






RGB FUNCTIONS (CONTINUED)

PRESS FN +] FOR LIGHT CYCLE
* INDICATES CYCLE LIGHT FUNCTION
PRESS FN + BACKSPACE TO TURN OFF

◆SOLID COLOR*
◆FULL KEYBOARD CHANGES COLOR*
◆WAVE FROM RIGHT TO LEFT*
◆SPIN FROM CENTER*
◆WAVE FROM BOTTOM TO TOP*
◆FN + [- BRIGHTNESS UP
◆FN + P - BRIGHTNESS DOWN
◆FN + ; - LIGHT SPEED SLOWS
◆FN + ' - LIGHT SPEED FASTER






ARROW KEYS

PRESS FN + THE CORRESPONDING KEY
FN + W FOR ARROW ONLY LOCK
REPEAT TO TURN OFF OR FN + Q

♦ / - UP ARROW
♦ ALT - LEFT ARROW
♦ MENU - DOWN ARROW
♦ CTRL - RIGHT ARROW





MISCELLANEOUS FUNCTIONS

PRESS FN + THE CORRESPONDING KEY
FN + W FOR ARROW ONLY LOCK
REPEAT TO TURN OFF OR FN + Q

◆ WIN KEY - DISABLES WIN KEY
◆ ESC - GRAVE ACCENT (`)
◆ SHIFT + ESC - TILDE (~)

